

# CS 318 Principles of Operating Systems

Fall 2020

## Lecture 14: I/O & Disks

Prof. Ryan Huang



JOHNS HOPKINS

WHITING SCHOOL  
of ENGINEERING

# Administrivia

- **Lab 3 is out, please start early**
  - Due Nov 12<sup>th</sup>
  - This is what many students in the past consider the most challenging lab
    - Design is important, Debugging is hard, also need to fix Lab 2 bugs
  - Strongly suggest coming up with the main design first and making an appointment with the staff to check the design.
- **Lab 3 overview session this Wednesday 8-9pm EDT**
- **Thursday is Fall break, no class**
- **Next Tuesday is Midterm**

# Midterm Logistics

- **Time: 75+5 minutes, Two Time Blocks**
  - October 27<sup>th</sup> Tuesday 1:00-3:00 pm EDT (for most students)
  - October 27<sup>th</sup> Tuesday 7:00-9:30 pm EDT (for students in distant time zones)
- **Exam will be released on Gradescope**
- **You will be able to access lectures slides and Piazza (for asking private clarification questions)**
  - Before entering the test in the lockdown browser, know your Piazza credentials, since you need to login in if you want to ask questions during the exam.
  - Prepare an image/pdf of your signature and store it in your computer
- **Give the ‘Test Midterm’ in Gradescope a try**

# Overview

- **We've covered OS abstractions for CPU and memory so far**
- **I/O management is another major component of OS**
  - Important aspect of computer operation
  - I/O devices vary greatly
  - Various methods to control them
  - Performance management
  - New types of devices frequent
- **Ports, buses, device controllers connect to various devices**


# I/O Devices



- **Issues to address:**

- How should I/O be integrated into systems?
- What are the general mechanisms?
- How can we make the efficiently?


# Structure of Input/Output (I/O) Device



# I/O Device Interfaces

- **Port – connection point for device**
  - serial port
- **Bus – daisy chain or shared direct access**
  - PCI bus common in PCs and servers, PCI Express (PCIe)
  - expansion bus connects relatively slow devices
- **Controller (host adapter) – electronics that operate port, bus, device**
  - Sometimes integrated
  - Sometimes separate circuit board (host adapter)
  - Contains processor, microcode, private memory, bus controller, etc
  - Some talk to per-device controller with bus controller, microcode, memory, etc

# What Is I/O Bus? E.g., PCI





# Device Interaction

- **How the OS communicates with the device?**
- **I/O instructions control devices**
  - `in` and `out` instructions on x86
  - Devices usually have **registers**
    - device driver places commands, addresses, and data there to read/write
- **Memory-mapped I/O**
  - Device registers available as if they were memory locations.
  - OS `load` (to read) or `store` (to write) to the device instead of main memory.

# Device I/O Port Locations on PCs

I/O address range (hexadecimal)	device
000–00F	DMA controller
020–021	interrupt controller
040–043	timer
200–20F	game controller
2F8–2FF	serial port (secondary)
320–32F	hard-disk controller
378–37F	parallel port
3D0–3DF	graphics controller
3F0–3F7	diskette-drive controller
3F8–3FF	serial port (primary)


# x86 I/O instructions

```
static inline uint8_t inb (uint16_t port)
{
    uint8_t data;
    asm volatile ("inb %w1, %b0" : "=a" (data) : "Nd" (port));
    return data;
}
```


```
static inline void outb (uint16_t port, uint8_t data)
{
    asm volatile ("outb %b0, %w1" : : "a" (data), "Nd" (port));
}
```

```
static inline void insw (uint16_t port, void *addr, size_t cnt)
{
    asm volatile ("rep insw" : "+D" (addr), "+c" (cnt)
                  : "d" (port) : "memory");
}
```

# Canonical I/O Device




# Canonical I/O Device



Canonical Device

# Canonical I/O Device



Canonical Device

# Hardware Interface Of Canonical Device

- **status register**
  - See the current status of the device
- **command register**
  - Tell the device to perform a certain task
- **data register**
  - Pass data to the device, or get data from the device
- **By reading or writing the above three registers, the OS controls device behavior.**

# Hardware Interface Of Canonical Device

- **Typical interaction example**

```
while (STATUS == BUSY)
    ; //wait until device is not busy
write data to data register
write command to command register
    Doing so starts the device and executes the command
while (STATUS == BUSY)
    ; //wait until device is done with your request
```



# IDE Disk Driver

```
void IDE_ReadSector(int disk, int off,
                   void *buf)
{
    // Select Drive
    outb(0x1F6, disk == 0 ? 0xE0 : 0xF0);
    IDEWait();
    // Read length (1 sector = 512 B)
    outb(0x1F2, 1);
    outb(0x1F3, off); // LBA low
    outb(0x1F4, off >> 8); // LBA mid
    outb(0x1F5, off >> 16); // LBA high
    outb(0x1F7, 0x20); // Read command
    insw(0x1F0, buf, 256); // Read 256 words
}
```

```
void IDEWait()
{
    // Discard status 4 times
    inb(0x1F7); inb(0x1F7);
    inb(0x1F7); inb(0x1F7);
    // Wait for status BUSY flag to clear
    while ((inb(0x1F7) & 0x80) != 0);
}
```

# Memory-mapped IO

- **in/out instructions slow and clunky**
  - Instruction format restricts what registers you can use
  - Only allows  $2^{16}$  different port numbers
  - Per-port access control turns out not to be useful (any port access allows you to disable all interrupts)
- **Devices can achieve same effect with physical addresses, e.g.:**

```
volatile int32_t *device_control
    = (int32_t *) (0xc0100 + PHYS_BASE);
*device_control = 0x80;
int32_t status = *device_control;
```

  - OS must map physical to virtual addresses, ensure non-cachable

# Polling

- **OS waits until the device is ready by repeatedly reading the status register**
  - Positive aspect is simple and working.
  - **However, it wastes CPU time just waiting for the device.**
    - Switching to another ready process is better utilizing the CPU.




Diagram of CPU utilization by polling

# Interrupts

- Put the I/O request process to sleep and context switch to another
- When the device is finished, wake the process waiting for the I/O by interrupt
  - Positive aspect is allow to **CPU and the disk are properly utilized.**




Diagram of CPU utilization by interrupt

# Polling vs Interrupts

- **However, “interrupts is not always the best solution”**
  - If, device performs very quickly, interrupt will “slow down” the system.
- **E.g., high network packet arrival rate**
  - Packets can arrive faster than OS can process them
  - Interrupts are very expensive (context switch)
  - Interrupt handlers have high priority
  - In worst case, can spend 100% of time in interrupt handler and never make any progress – *receive livelock*
  - Best: Adaptive switching between interrupts and polling

If a device is fast → **poll** is best.  
If it is slow → **interrupts** is better.

# One More Problem: Data Copying

- **CPU wastes a lot of time in copying *a large chunk of data* from memory to the device.**





Diagram of CPU utilization

# DMA (Direct Memory Access)



- **Idea: only use CPU to transfer control requests, not data**
- **Include list of buffer locations in main memory**
  - Device reads list and accesses buffers through DMA
  - Descriptions sometimes allow for scatter/gather I/O

# DMA (Direct Memory Access) Cont.

- **When completed, DMA raises an interrupt, I/O begins on Disk.**





Diagram of CPU utilization by DMA




# Direct Memory Access

- **Avoid programmed I/O for large data movement**
- **Requires DMA controller**
- **Bypasses CPU to transfer data directly between I/O device and memory**
- **OS writes DMA command block into memory**
  - Source and destination addresses
  - Read or write mode
  - Count of bytes
  - Writes location of command block to DMA controller

# Example: IDE disk read w. DMA




# Example: Network Interface Card



- **Link interface talks to wire/fiber/antenna**
  - Typically does framing, link-layer CRC
- **FIFOs on card provide small amount of buffering**
- **Bus interface logic uses DMA to move packets to and from buffers in main memory**

# Protocol Variants



- **Status checks:** *polling* vs. *interrupts*
- **Data:** *programmed I/O* (PIO) vs. *direct memory access* (DMA)
- **Control:** *special instructions* vs. *memory-mapped I/O*

# Variety Is a Challenge


- **Problem:**
  - many, many devices
  - each has its own protocol
- **How can we avoid writing a slightly different OS for each H/W combination?**

# Variety Is a Challenge


- **Problem:**
  - many, many devices
  - each has its own protocol
- **How can we avoid writing a slightly different OS for each H/W combination?**
- **Solution: Abstraction!**
  - Build a common interface
  - Write device driver for each device
  - Drivers are 70% of Linux source code

# File System Abstraction

- **File system specifics of which disk class it is using.**
  - Ex) It issues **block read** and **write** request to the generic block layer.



# Hard Disks






# Hard Disks



# Hard Disks



# Basic Interface

- **Disk interface presents linear array of sectors**
  - Historically **512 Bytes**
  - Written atomically (even if there is a power failure)
  - 4 KiB in “advanced format” disks
    - Torn write: If an untimely power loss occurs, only a portion of a larger write may complete
- **Disk maps logical sector #s to physical sectors**
- **OS doesn't know logical to physical sector mapping**

# Basic Geometry



- **Platter (Aluminum coated with a thin magnetic layer)**
  - A circular hard surface
  - Data is stored persistently by inducing magnetic changes to it.
  - Each platter has 2 sides, each of which is called a **surface**.

# Basic Geometry (Cont.)

- **Spindle**

- Spindle is connected to a motor that spins the platters around.
- The rate of rotations is measured in **RPM** (Rotations Per Minute).
  - Typical modern values : 7,200 RPM to 15,000 RPM.


- **Track**

- Concentric circles of **sectors**
- Data is encoded on each surface in a track.
- A single surface contains many thousands and thousands of tracks.


- **Cylinder**

- A stack of tracks of fixed radius
- Heads record and sense data along cylinders
- Generally only one head active at a time

# Cylinders, Tracks, & Sectors




# A Simple Disk Drive



A Single Track Plus A Head

- **Disk head (One head per surface of the drive)**
  - The process of *reading* and *writing* is accomplished by the **disk head**.
  - Attached to a single disk arm, which moves across the surface.

# Single-track Latency: The Rotational Delay




A Single Track Plus A Head

- **Rotational delay: Time for the desired sector to rotate**
  - Ex) Full rotational delay is  $R$  and we start at sector 6
    - Read sector 0: Rotational delay =  $\frac{R}{2}$
    - Read sector 5: Rotational delay =  $R-1$  (worst case.)




# Multiple Tracks

- **Let's Read 12!**




# Multiple Tracks: Seek To Right Track

- **Let's Read 12!**




# Multiple Tracks: Seek To Right Track

- **Let's Read 12!**




# Multiple Tracks: Seek To Right Track

- **Let's Read 12!**




# Multiple Tracks: Wait for Rotation

- **Let's Read 12!**



# Multiple Tracks: Wait for Rotation

- **Let's Read 12!**




# Multiple Tracks: Wait for Rotation

- **Let's Read 12!**



# Multiple Tracks: Wait for Rotation


- **Let's Read 12!**






# Multiple Tracks: Wait for Rotation

- **Let's Read 12!**




# Multiple Tracks: Wait for Rotation

- **Let's Read 12!**




# Multiple Tracks: Transfer Data

- **Let's Read 12!**




# Multiple Tracks: Transfer Data

- **Let's Read 12!**




# Multiple Tracks: Transfer Data


- **Let's Read 12!**



# Yay!



# Multiple Tracks: Seek Time



- **Seek: Move the disk arm to the correct track**
  - **Seek time:** Time to move head to the track contain the desired sector.
  - One of the most costly disk operations.

# Seek, Rotate, Transfer

- **Acceleration → Coasting → Deceleration → Settling**
  - **Acceleration:** The disk arm gets moving.
  - **Coasting:** The arm is moving at full speed.
  - **Deceleration:** The arm slows down.
  - **Settling:** The head is *carefully positioned* over the correct track.
- **Seeks often take several milliseconds!**
  - settling alone can take 0.5 to 2ms.
  - entire seek often takes 4 - 10 ms.



# Seek, Rotate, Transfer

- **Depends on rotations per minute (RPM)**
  - 7200 RPM is common, 15000 RPM is high-end.
- **With 7200 RPM, how long to rotate around?**
  - $1 / 7200 \text{ RPM} = 1 \text{ minute} / 7200 \text{ rotations} = 1 \text{ second} / 120 \text{ rotations} = 8.3 \text{ ms} / \text{rotation}$
- **Average rotation?**
  - $8.3 \text{ ms} / 2 = 4.15 \text{ ms}$


# Seek, Rotate, Transfer

- **The final phase of I/O**
  - Data is either *read from* or *written* to the surface.
- **Pretty fast — depends on RPM and sector density**
- **100+ MB/s is typical for maximum transfer rate**
- **How long to transfer 512-bytes?**
  - $512 \text{ bytes} * (1\text{s} / 100 \text{ MB}) = 5 \mu\text{s}$

# Workload

- **So...**
  - seeks are slow
  - rotations are slow
  - transfers are fast
- **What kind of workload is fastest for disks?**
  - **Sequential**: access sectors in order (transfer dominated)
  - **Random**: access sectors arbitrarily (seek+rotation dominated)

# Disk Scheduling



- **Disk Scheduler decides which I/O request to schedule next**


# Disk Scheduling: FCFS

- **“First Come First Served”**
  - Process disk requests in the order they are received
- **Advantages**
  - Easy to implement
  - Good fairness
- **Disadvantages**
  - Cannot exploit request locality
  - Increases average latency, decreasing throughput

# FCFS Example

queue = 98, 183, 37, 122, 14, 124, 65, 67

head starts at 53




# SSTF (Shortest Seek Time First)

- **Order the queue of I/O request by track**
- **Pick requests on the nearest track to complete first**
  - Also called shortest positioning time first (SPTF)
- **Advantages**
  - Exploits locality of disk requests
  - Higher throughput
- **Disadvantages**
  - Starvation
  - Don't always know what request will be fastest

# SSTF Example

queue = 98, 183, 37, 122, 14, 124, 65, 67

head starts at 53






# “Elevator” Scheduling (SCAN)

- **Sweep across disk, servicing all requests passed**
  - Like SSTF, but next seek must be in same direction
  - Switch directions only if no further requests
- **Advantages**
  - Takes advantage of locality
  - Bounded waiting
- **Disadvantages**
  - Cylinders in the middle get better service
  - Might miss locality SSTF could exploit
- **CSCAN: Only sweep in one direction**
  - **Very commonly used algorithm in Unix**

# CSCAN example

queue 98, 183, 37, 122, 14, 124, 65, 67

head starts at 53



# Flash Memory

- **Today, people increasingly using flash memory**
- **Completely solid state (no moving parts)**
  - Remembers data by storing charge
  - Lower power consumption and heat
  - No mechanical seek times to worry about
- **Limited # overwrites possible**
  - Blocks wear out after 10,000 (MLC) – 100,000 (SLC) erases
  - Requires flash translation layer (FTL) to provide wear leveling, so repeated writes to logical block don't wear out physical block
  - FTL can seriously impact performance
- **Limited durability**
  - Charge wears out over time
  - Turn off device for a year, you can potentially lose data!

# Next Time...

- **Read Chapter 39, 40**